

1637 Mk II – How to Clear the Internal Sample Log

This technical note describes the process to clear the internal sample log on the Novatech Controls 1637 Mk-II Oxygen & Carbon Dioxide Food Packaging Analyser using the menu system.

1. Enable *Extended Display Mode*

From the main screen, **press hand hold the UPΔ button for approximately 5 seconds.**

In *Extended Display Mode* the writing on the display will look similar to that in the picture to the right ->

Release the UPΔ button.



2. Enter the Configuration Menu

From the *Extended Display Mode* screen, **press and hold the ENTER button for approximately 3 seconds.**

After 3 seconds you will hear a beep and the display will show the words Entering Configuration Menu.

Release the ENTER button



3. Navigate to the Products & Log Menu

Press the DOWN button twice until the number next to the small cursor shows '11'.

4. Select the 'Reset Internal Log' Item

Press ENTER to move the cursor next to the menu item labelled 'Reset Internal Log'



5. Reset the Internal Log

Press ENTER to clear the sample log. The display will briefly show the words Log Cleared.

To exit the menu system press the LOG button twice.

To exit *Extended Display Mode* press and hold the UPΔ button for approximately 5 seconds.

